




Parts Manual

MAGNUM

TK 51745-4-PM (Rev. 4.14)

MAGNUM

TK 51745-4.14



Printed (August 9, 2012)

Copyright © 2002 - Thermo King Corp. - Minneapolis, MN U.S.A.
Electronically printed in U.S.A.

General Information

Tables of Contents

This Parts Manual contains a numerical table of contents listing each assembly name, its associated Grid number and page number. The numerical table of contents is arranged numerically by Grid number. There are references in a parts list referring to other Grid numbers, the numerical table of contents is arranged to facilitate finding the referenced illustrations. At the rear of this parts manual are two indexes, a numerical and alphabetical. The indexes contain all of the part numbers and descriptions which appear in this manual.

Assemblies and Subassemblies

When parts are indented in the description list, they are preceded with a bullet (•). This indicates that the part(s) is available separately or included in an assembly.

GRID NO. 67D6 SWITCH PANEL ASSEMBLY

REF	PART#	DESCRIPTION	QTY
	45-1239	PANEL - assy, switch	1
1	99-1960	• PANEL	1
	99-6280	• • NAMEPLATE - panel	1
2	33-743	• GASKET	1

For example: the switch panel nameplate (99-6280) is available separately, available as part of the switch panel (99-1960) and with the panel assembly (45-1239).

ABBREVIATIONS


The following abbreviations appear in parts manuals

A AC alternating current	E (continued)	O os oversized
A/R as required	evap. evaporator	od outside diameter
accum accumulator	exch exchanger	P pcb printed circuit board
adj adjusting	exp expansion	pkg package
al aluminum	ext external	ph phase
alt. alternator	F F Fahrenheit	pos positive
A or amp ampere	fill fillister	psi pounds per square inch
assy assembly	fi fuel injection	
B bd board	fl flare	R rad radiator
brg bearing	fpt female pipe thread	rcvr receiver
brkr breaker	ft feet	ref reference
brkt bracket	ftg fitting	reg regulator
C C Celsius	H hex hexagon	req required
cw clockwise	hh hexagon head	rpm revolutions per minute
ccw counter-clockwise	hd head	S sec second
cam camshaft	hp horsepower	sld solder
compr compressor	hsg housing	soc hd. socket head
cond. condenser	I id inside diameter	sol solenoid
conn. connecting, connector	in inch (2.54 centimeters)	spl special
cyl cylinder	incl includes	sq square
D def defrost	inj injection	ss stainless steel
deg degree	int internal	std. standard
dehyd. dehydrator	int th internal tooth	stl steel
dia diameter	L liq liquid	suct. suction
DC direct current	lg long	sw switch
disch discharge	M mm millimeter	T term terminal
diff differential	mpt male pipe thread	temp temperature
E EMI Extended	mod modulating	thk. thick
. Maintenance Interval	N neg negative	U us undersize
EEC European Economic Community	No. number	V vib vibrasorber
eng engine	NS not supplied	W W watt
	NSS not sold separately	w/ with
		w/o without

MAGNUM


Contents

Name	Grid	Page
MAGNUM REFERENCE SHEET	7U94.....	3
AIR VENT (40 FT CONTAINERS).....	143D7.....	81
RECORDING THERMOMETER - 31 DAY FAHRENHEIT	147B2.....	53
RECORDING THERMOMETER (OPTION 098026 & 098030).....	147B8.....	49
RECORDING THERMOMETER (OPTION 098026)	147B9.....	55
TRANSFORMER GROUP (098024, 098040, 098041, 098043, 098071, 098123, 098128)	148G2.....	47
WATER COOLED CONDENSER	154E13.....	29
AIR VENT (20 FT CONTAINERS).....	157D9.....	85
USDA DOWNLOAD PANEL (CANNON CONNECTORS)	157H2.....	63
HIGH VOLTAGE TRAY	158A1.....	41
REMOTE MONITOR OPTION (098182 CSR; 098144 CRR; 098182 CSR)	158A5.....	61
GAUGE GROUP (OPTION 098140)	158B4.....	31
AFAM MP3000 (OPTION 098166)	158H7.....	87
USDA DOWNLOAD PANEL (3-PIN DEUTSCH CONNECTORS)	160F3.....	65
EVAPORATOR PANELS.....	160G6.....	91
DEFROST DRAIN	173B6.....	93
REFRIGERATION COMPONENTS	180D0.....	13
CONDENSER FAN GROUP	180D8.....	5
EVAPORATOR FAN GROUP (MAGNUM 40).....	180D9.....	7
COMPRESSOR GROUP (SERVICE VALVES)	180E1.....	27
ELECTRICAL COMPONENTS	180E2.....	33
CONTROL BOX.....	180E3.....	37
NAMEPLATES.....	180E6.....	97
CONTROL BOX DOOR (MP3000-A w/ RMM)	183B5.....	43
EVAPORATOR FAN GROUP (THREE FANS).....	183B6.....	11
CONDENSER COMPONENTS (20 ft CONTAINER, THREE FANS)	183B7.....	73
REFRIGERATION COMPONENTS (WCC, SERVICE VALVES)	189B9.....	23
CONDENSER COMPONENTS.....	189C2.....	69
DEFROST DRAIN	189C4.....	95
REFRIGERATION COMPONENTS (SERVICE VALVES)	189D5.....	17
USDA DOWNLOAD PANEL (4-PIN DEUTSCH CONNECTORS)	189D7.....	67
AIR VENT (40 FT CONTAINERS).....	191B6.....	83
ELECTRONIC CHART RECORDER.....	212G9.....	57
AIR VENT (AFAM MP3000)	213D3.....	89
DOWNLOAD CABLES	226E2.....	45
CONDENSER COMPONENTS (11/05 & after).....	226E3.....	77





B/M	DESCRIPTION	Date
098525	MAGNUM 40 w/ AFAM+	11/02
098528	MAGNUM	11/02
098540	MAGNUM	2/06
098546	MAGNUM	2/06
098547	MAGNUM	2/06
098552	MAGNUM	2/06
098553	MAGNUM	2/06
098554	MAGNUM	2/06
098916	MAGNUM 20	11/02
098922	MAGNUM 40	11/02
098924	MAGNUM - 924	1/08
098934	MAGNUM 40 SL	10/10






REF	PART#	DESCRIPTION	QTY
1	60-285	COIL - condenser	1
	33-2950	GASKET (10 x 15 mm)	A/R
	51-1442	SCREW - coil	7
	51-1444	FLATWASHER	7
	55-9054	WASHER (nylon)	7
2	78-1167	FAN - condenser (21.6 in, 500 mm dia, 30 deg pitch, 8 blade)	1
3	104-759	MOTOR - condenser fan (0.75 hp)	1
	77-1498	• BEARING - shaft end	1
	77-1401	• BEARING - opposite end	1
	51-1443	SCREW - motor	4
	51-1444	FLATWASHER	8
	51-1429	LOCKWASHER	4
	51-1427	NUT	4
4	55-5900	GRIP - cable	1
5	33-367	GROMMET	1
6	41-2953	HARNESS - condenser fan	1




REF	PART#	DESCRIPTION	QTY
1	98-6562	HOUSING - evaporator (12 in, 312 mm dia)	1
	98-6566	HOUSING - evaporator (14 in, 355 mm dia fans)	1
2	92-2779	• BRACKET - motor (left)	2
3	92-2332	• BRACKET - motor (right)	2
	55-9162	RIVET - housing	10
4	33-3215	GROMMET (47 mm)	1
5	33-3044	TRIM - edge guard	A/R
6	55-5900	CONNECTOR - harness & sensor	2
7	78-1117	FAN - evaporator (14 in, 355 mm dia, ccw, 8 blade)	2
	78-1349	FAN - evaporator (12 in, 312 mm dia, ccw, 6 blade)	2
	78-1524	FAN - evaporator (top air, 14 in, 355 mm dia, cw, 8 blade)	2
8	NSS	COIL - evaporator (see Refrigeration Group)	1
	55-8891	SCREW - coil	9
	55-9217	CAP - screw	3
9	91-9328	BLOCK - coil	2
10	41-4018	HARNESS - evaporator fan (MAGNUM)	1
	41-3685	HARNESS - evaporator fan (MAGNUM SL-40)	1
11	104-691	MOTOR - fan	2
	77-1498	• BEARING - shaft end	1
	77-1401	• BEARING - opposite end	1
	51-1443	SCREW - motor	8
	55-7066	LOCKWASHER (external tooth)	2
	55-7342	LOCKWASHER	6
	55-7085	FLATWASHER	8
	92-425	NUTSTRIP	4
12	99-4931	NAMEPLATE - Arrow	1
13	91-8466	BRACKET - motor	2
	55-6993	SCREW - bracket	8
	51-1444	FLATWASHER	16
	51-1429	LOCKWASHER	8
	55-7339	NUT	8
14	92-458	FILTER - gas sensor	1
15	33-2946	GROMMET (37 mm)	6
16	92-2775	COVER - tube	1
	55-7172	SCREW - cover	3
	55-8877	WASHER (nylon)	3
	55-7075	FLATWASHER	3
17	33-367	GROMMET	3
18	92-456	BRACKET - sensor	1
	55-7035	SCREW - sensor	2
	55-7075	FLATWASHER	2
	55-8877	WASHER - insulating	2






REF	PART#	DESCRIPTION	QTY
	92-2587	NUTSTRIP - bracket	1
19	41-9768	SENSOR - gas (O2/CO2)	1
	41-9490	SENSOR - gas (CO2 only)	1
20	11-4367	HOSE - sensor (1/4 od x 35 ft lg)	A/R
21	33-3838	GROMMET (22 mm)	1






REF	PART#	DESCRIPTION	QTY
1	104-691	MOTOR - fan	3
	77-1498	• BEARING - shaft end	1
	77-1401	• BEARING - opposite end	1
	55-6993	SCREW - motor (25 mm)	12
	55-8903	SCREW - motor (22 mm)	12
	55-8904	FLATWASHER	12
	55-8805	LOCKWASHER	15
	55-7339	NUT	12
	55-8986	INSERT - threaded	12
2	78-1196	FAN - evaporator (10 in, 254 mm dia)	3
3	91-8466	BRACKET - motor	3
	55-8903	SCREW - bracket	12
	55-6988	FLATWASHER	21
4	98-6564	BRACKET - motor mount	1
5	92-2790	• BRACKET - motor	3
6	92-2791	• BRACKET - motor	3
	55-8891	SCREW - bracket	17
7	33-3215	GROMMET (47 mm)	1
8	33-2946	GROMMET (37 mm)	7
9	33-3838	GROMMET (22 mm)	1
10	55-2324	KEY - fan	3
11	67-1922	COIL - evaporator	1
	55-8891	SCREW - coil	18
	55-7342	LOCKWASHER	18
	55-7066	FLATWASHER	6
	55-9217	CAP - screw	9
12	91-9328	BLOCK - coil	2
13	55-8907	CONNECTOR - harness	3
	55-8908	NUT	3
14	41-4002	HARNESS - evaporator fan	1
15	51-270	CONNECTOR - grip (sensor)	1
16	92-2778	COVER - tube	1
	55-7172	SCREW - cover	3
	55-8872	WASHER (nylon)	3
	55-7075	FLATWASHER	3
17	33-367	GROMMET	3






REF	PART#	DESCRIPTION	QTY
1	102-795	COMPRESSOR - scroll (see 180E1)	1
2	66-9181	TUBE - valve to coil (units w/ valves)	1
	61-175	TUBE - flange to coil (units w/ flanges)	1
3	60-285	COIL - condenser	1
	55-7035	SCREW - coil	8
	55-8893	FLATWASHER	7
	55-9054	WASHER	8
4	67-1890	TANK - receiver	1
5	66-7812	• FITTING - high side	1
	66-7182	•• CAP - fitting	1
6	61-1852	• TUBE - coil to receiver tank	1
7	506-364	• PLUG - fusible	1
8	61-1853	• TUBE - tank to dehydrator	1
9	66-8811	• INDICATOR - liquid	1
	33-3007	• O-RING	1
10	61-786	DEHYDRATOR (o-ring seal)	1
	33-3007	O-RING	2
11	55-4390	HANGER - dehydrator	1
	55-8316	SCREW - hanger	1
	55-7075	FLATWASHER	2
	55-7042	NUT	1
12	61-1848	TUBE - filter	1
	55-302	NUT - filter	1
13	61-1844	TUBE - dehydrator to tee	1
14	61-1845	TUBE - tee to valve	1
15	67-1889	HEAT EXCHANGER - economizer	1
16	92-2588	BRACKET - exchanger	1
17	92-2589	COVER - exchanger	1
	55-6994	SCREW - cover	2
	55-7075	FLATWASHER	4
	55-7042	NUT	2
18	61-1843	TUBE - tee to exchanger	1
19	55-3251	TEE (3/8)	1
20	41-5103	VALVE - solenoid (vapor injection)	1
21	41-3301	COIL - valve	1
22	61-1846	TUBE - valve to expansion	1
23	61-1847	TUBE - expansion valve to tee	1
24	66-9906	VALVE - expansion (economizer)	1
25	61-1849	TUBE - liquid injection	1
	55-8951	SHOULDER	1
	55-8950	NUT - o-ring seal	1






REF	PART#	DESCRIPTION	QTY
26	33-566	O-RING	1
27	61-1850	TUBE - valve to evaporator	1
28	67-1923	COIL - evaporator (14.7/374 wide, MAGNUM)	1
	67-1921	COIL - evaporator (13.0/330 wide, MAGNUM SL-40)	1
	67-1922	COIL - evaporator (11.3/286 wide, MAGNUM SL-20)	1
	55-6993	SCREW (25 mm)	8
	55-9541	FLATWASHER (8.4 mm)	14
	55-6988	FLATWASHER (8.4 mm id)	14
29	61-2117	TUBE - coil to valve (units w/ service valves)	1
	61-1839	TUBE - coil to flange (units w/ flanged compressor)	1
30	Not Used		
31	66-874	FITTING - flare	1
	66-6607	FITTING - low side	1
	66-7183	• CAP - charge port (blue)	1
	66-8054	ADAPTER	1
32	41-4473	SWITCH - lpco	1
33	61-1840	TUBE - suction to valve	1
34	61-2057	VALVE - digital	1
	41-7937	• COIL (only)	1
35	61-2467	TUBE - valve to compressor	1
36	61-2162	ADAPTER - compressor	1
37	91-4774	CLAMP - suction tube	1
38	91-1779	CLAMP - strap	1
	55-7027	SCREW - clamp	2
	55-7075	FLATWASHER	2
39	55-6388	CLAMP - tube (3/8)	3
	91-759	CLAMP - tube (1/2)	1
	55-8915	SPACER (18 mm)	4
	55-7029	SCREW - clamp (65 mm)	2
	55-8993	SCREW - clamp (50 mm)	2
	55-9027	WASHER (nylon)	2
40	55-2296	TEE (1/2)	1
41	61-2051	TUBE - tee to distributor	2
42	61-443	VALVE - expansion	1
43	61-2048	TUBE - equalizer	1
	61-2054	TUBE - equalizer (MAGNUM 20)	1
44	61-2049	TUBE - expansion valve to tee	1
	61-2052	TUBE - expansion valve to tee (MAGNUM 20)	1
45	61-2050	TUBE - expansion valve to inlet	1
	61-2053	TUBE - expansion valve to inlet (MAGNUM 20)	1






REF	PART#	DESCRIPTION	QTY
1	102-795	COMPRESSOR - scroll (see 180E1)	1
	92-2229	SPACER - compressor	1
2	61-2477	TUBE - valve to coil	1
3	60-285	COIL - condenser	1
4	61-2467	TUBE - valve to coil	1
5	61-2162	ADAPTER - compressor	1
6	33-3912	SEAL - teflon fiber	1
7	67-1991	TANK - receiver	1
8	61-2238	• TUBE - receiver to dehydrator	1
9	61-2569	• TUBE - receiver to condenser	1
10	66-7812	CAP - fitting	1
	66-7182	• CAP - fitting	1
11	66-8811	INDICATOR - liquid	1
	33-3007	O-RING	1
12	506-364	PLUG - fusible	1
	51-273	NUT - receiver tank	2
	55-9027	WASHER - insulating	4
	55-7347	LOCKWASHER	2
13	55-6730	CLAMP - tube	2
	55-7372	SCREW - clamp	1
	55-7075	FLATWASHER	2
	55-7042	NUT	1
14	61-2475	TUBE - receiver to dehydrator	1
	203-454	MASTIC - heat transfer	A/R
15	61-786	DEHYDRATOR	1
16	55-4390	CLAMP - dehydrator	1
	55-8464	SCREW - clamp	1
	55-8893	FLATWASHER	1
	55-9054	WASHER - insulating	1
	55-8316	SCREW - dehydrator	1
	55-7075	FLATWASHER	2
	55-7042	NUT	1
17	61-1848	TUBE - filter	1
18	61-2473	TUBE - filter to tee	1
19	55-3251	TEE	1
20	61-2471	TUBE - tee to exchanger	1
21	67-1889	HEAT EXCHANGER - economizer	1
	92-3547	INSULATION - heat exchanger	1
22	61-2472	TUBE - tee to valve	1
	91-758	CLAMP - tube	1
	55-9912	SCREW - clamp	1
	55-7075	FLATWASHER	2






REF	PART#	DESCRIPTION	QTY
	55-8915	SPACER	1
23	61-2470	VALVE - solenoid (vapor injection)	1
24	41-5460	COIL - valve	1
25	61-2469	TUBE - valve to expansion	1
26	66-9906	VALVE - expansion (economizer)	1
27	61-1847	TUBE - expansion valve to exchanger	1
28	61-2474	TUBE - liquid injection	1
	55-8951	SHOULDER	1
	55-8950	NUT - o-ring seal	1
	92-3548	INSULATION - tube (24.5 in lg)	1
	92-3549	INSULATION - tube (19.0 in lg)	1
	91-1800	CLAMP - tube	2
	55-7372	SCREW - clamp	1
	55-7042	NUT	1
29	61-2476	TUBE - tx bulb	1
30	92-3391	BRACKET - heat exchanger	1
	92-3550	INSULATION - mylar	1
31	61-2464	TUBE - suction (before 4/05)	1
	61-3502	TUBE - suction (4/05 & after)	1
	92-3551	INSULATION - tube (42.1 in lg)	1
	92-3552	INSULATION - tube (5.5 in lg)	1
32	61-2466	TUBE - suction to ball valve	1
33	61-2465	VALVE - ball	1
34	61-2057	VALVE (PWM)	1
	41-7937	• COIL (only)	1
35	66-874	FITTING - flare	1
	66-6607	FITTING - low side	1
	66-7183	• CAP - charge port (blue)	1
	66-8054	ADAPTER	1
36	41-4473	SWITCH - lpco	1
37	33-566	O-RING	1
38	61-2468	TUBE - heat exchanger to evaporator	1
	92-3553	INSULATION - tube (14.1 in lg)	1
39	61-2050	TUBE - exchanger to coil (#2)	1
40	61-443	VALVE - expansion	1
	92-2228	SPACER - clamp	1
	55-6388	CLAMP - valve	1
	55-9759	SCREW - clamp	1
	55-8316	SCREW - dehydrator clamp	1
	55-7075	FLATWASHER	2
	55-7042	NUT	1
41	61-2048	TUBE - equalizer	1






REF	PART#	DESCRIPTION	QTY
42	61-2049	TUBE - expansion valve to tee	1
43	55-2296	TEE	1
44	61-2051	TUBE - tee to distributor	1
45	67-1923	COIL - evaporator (14.7/374 wide, see 180D9)	1
	67-1921	COIL - evaporator (13.0/330 wide, MAGNUM SL-40, see 183B4)	1
	67-1922	COIL - evaporator (11.3/286 wide, MAGNUM SL-20, see 183B6)	1
46	41-6150	TRANSDUCER - suction (200 psi)	1
47	41-6151	TRANSDUCER - discharge (500 psi)	1
48	55-6388	CLAMP - tube (3/8)	3
	91-759	CLAMP - tube (1/2)	1
	55-8915	SPACER (18 mm)	4
	55-7029	SCREW - clamp (65 mm)	2
	55-8993	SCREW - clamp (50 mm)	2
	55-9027	WASHER (nylon)	2






REF	PART#	DESCRIPTION	QTY
1	102-795	COMPRESSOR - scroll (see 180E1)	1
2	61-2477	TUBE - valve to coil	1
3	60-285	COIL - condenser	1
4	61-2467	TUBE - valve to compressor	1
5	61-2162	ADAPTER - compressor	1
6	33-3912	SEAL - teflon fiber	1
	66-7543	TUBE (0.500 od x 1.880 lg cu)	1
	66-9447	TUBE (0.500 od x 2.250 lg cu)	1
7	67-1575	TANK - water cooled condenser (see 154E13)	1
8	61-3504	TUBE - condenser to tee	1
9	61-3525	VALVE - ball	1
10	61-3542	TUBE - valve to dehydrator	1
11	61-1305	TUBE - condenser to condenser	1
12	61-786	DEHYDRATOR (o-ring seal)	1
	55-4390	CLAMP - dehydrator	1
	51-1440	SCREW - clamp	1
	51-1441	FLATWASHER	2
	51-1425	NUT	1
13	61-3503	TUBE - filter	1
14	55-3251	TEE	1
15	61-2471	TUBE - tee to exchanger	1
16	67-1889	HEAT EXCHANGER - economizer	1
17	61-2472	TUBE - tee to valve	1
18	61-2470	VALVE - solenoid (vapor injection)	1
19	41-5460	COIL - valve	1
20	61-2469	TUBE - valve to expansion	1
21	66-9906	VALVE - expansion (economizer)	1
22	61-1847	TUBE - expansion valve to exchanger	1
23	61-2474	TUBE - liquid injection	1
	55-8951	SHOULDER	1
	55-8950	NUT - o-ring seal	1
24	61-2468	TUBE - heat exchanger to evaporator	1
25	61-2050	TUBE - exchanger to coil (#2)	1
26	61-443	VALVE - expansion	1
	92-2228	SPACER - clamp	1
	55-6388	CLAMP - valve	1
	51-1439	SCREW - clamp	1
27	61-2048	TUBE - equalizer	1
28	61-2049	TUBE - expansion valve to tee	1
29	55-2296	TEE	1
30	61-2051	TUBE - tee to distributor	1
31	67-1923	COIL - evaporator (14.7/374 wide, see 180D9)	1






REF	PART#	DESCRIPTION	QTY
	67-1921	COIL - evaporator (13.0/330 wide, MAGNUM SL-40, see 183B4)	1
	67-1922	COIL - evaporator (11.3/286 wide, MAGNUM SL-20, see 183B6)	1
32	61-2464	TUBE - suction (before 4/05)	1
	61-3502	TUBE - suction (4/05 & after)	1
33	66-8054	ADAPTER	1
34	41-4473	SWITCH - lpco	1
35	61-2466	TUBE - suction to ball valve	1
36	61-2465	VALVE - ball	1
37	61-2057	VALVE (PWM)	1
	41-7937	• COIL (only)	1
38	33-566	O-RING	1
39	92-3391	BRACKET - heat exchanger	1
	51-1442	SCREW - bracket	2
	55-9054	WASHER - insulating	2
	51-1464	FLATWASHER	2
40	61-3508	TUBE - coil to dehydrator (units w/o WCC)	1
41	41-6150	TRANSDUCER - suction (200 psi)	1
42	41-6151	TRANSDUCER - discharge (500 psi)	1






REF	PART#	DESCRIPTION	QTY
1	102-795	COMPRESSOR - scroll	1
	203-516	OIL - compressor	A/R
	40-779	KIT - gasket & grease	1
2	33-2951	• GASKET - power connector	1
	33-2979	• SEALER - silicone grease pack	1
3	55-8994	• SCREW - ground	1
	55-8995	• WASHER - ground	1
4	91-9021	• COVER - terminal box	1
5	40-776	• KIT - thermistor	1
6	51-1433	SCREW - compressor	4
7	51-1435	FLATWASHER (12 mm)	4
8	55-9012	WASHER - vibration damper	4
9	55-9013	SPACER (before 1/03, height - 16.3, dia 31.7)	4
	51-1432	SPACER (1/03 - 3/10, height - 17.4, dia 34.3)	4
	51-2033	SPACER (3/10 & after, height - 17.9, dia 34.3)	4
10	51-1436	FLATWASHER (13 mm)	4
11	51-1434	NUT	4
12	41-4004	SWITCH - hpco	1
	203-393	SEALER - thread (red)	A/R
13	66-7812	ADAPTER - high side	1
	66-6610	FITTING - highside	1
	66-7182	• CAP - fitting	1
	203-393	SEALER - thread (red)	A/R
14	66-8054	ELBOW - low side	1
	66-6607	FITTING - low side	1
	66-7183	• CAP - fitting	1
15	33-727	O-RING - suction	1
16	51-1438	SCREW - flange	2
17	51-1429	LOCKWASHER	2
18	33-2805	GASKET - flange	1
19	51-1437	SCREW - discharge valve	2
20	51-358	WASHER - sealing	2
21	61-2119	VALVE - discharge	1
22	40-782	KIT - power cord	1
23	61-2118	VALVE - suction	1
	66-9842	VALVE	1
24	55-3364	PLUG	1






REF	PART#	DESCRIPTION	QTY
1	67-1575	TANK - water cooled condenser	1
2	66-8811	INDICATOR	1
3	33-3007	O-RING	1
4	66-6610	FITTING - high side	1
5	66-7182	• CAP - fitting	1
6	506-364	PLUG - fusible	1
	203-393	SEALER - locking	A/R
	51-1467	SCREW - tank	4
	51-1429	LOCKWASHER	4
	51-1430	FLATWASHER	4
7	66-4788	COUPLING - outlet	1
	203-385	SEALER - thread	A/R
8	91-6627	CAP - dust cover	1
9	55-1827	PLUG - outlet	1
10	91-6628	CAP - dust cover	1
11	61-3504	TUBE - condenser to filter	1
12	61-3525	VALVE - ball	1
13	61-3542	TUBE - valve to dehydrator	1
14	61-1305	TUBE - condenser to condenser	1
15	91-759	CLAMP - tube	2
	51-1462	SCREW - clamp	1
16	55-6730	CLAMP - tube	6
	55-7035	SCREW - clamp	2
	55-8893	FLATWASHER	4
17	66-7543	TUBE - stub (1.88 lg)	1
18	66-9447	TUBE - stub (2.25 lg)	1






REF	PART#	DESCRIPTION	QTY
1	92-219	PLATE - guard (w/ gauge)	1
2	33-3212	GASKET - gauge	1
3	66-9194	GAUGE - suction pressure	1
	55-8382	SCREW - gauge	3
	55-7830	FLATWASHER	3
	55-9086	WASHER - insulating	3
	55-7864	NUT	3
4	33-768	GASKET - round	2
5	61-154	TUBE - gauge (w/ activator)	1






REF	PART#	DESCRIPTION	QTY
1	40-791	KIT - sensor (universal)	A/R
2	41-3685	HARNESS - evaporator (two fan, see 180D9)	1
	41-4002	HARNESS - evaporator (three fan, see 183B6)	1
3	92-2777	BRACKET - power cable (11/4 cable)	1
	92-5660	BRACKET - power cable (10/4 cable)	1
	51-1445	SCREW - bracket	2
	51-1446	LOCKWASHER	2
	51-1441	FLATWASHER	2
	55-9054	WASHER - insulator	2
4	45-1992	CABLE - power (19.2 meters, 63 ft, 11/4 ga)	1
	45-237	CABLE - power (24 meters, 78 ft, 10/4 ga)	1
5	41-1976	• PLUG - power (Minnekes)	1
	44-4051	• PLUG - power (10/4)	1
	44-9891	• TERMINAL - pin	7
6	41-4473	SWITCH - lpco	1
7	91-8140	SPRING - heater	6
8	41-2838	HARNESS - sensor (humidity, MPC)	1
9	104-759	MOTOR - condenser fan (see 180D8)	1
	77-1498	• BEARING - shaft end	1
	77-1401	• BEARING - opposite end	1
10	41-2953	HARNESS - condenser fan (see 180D8)	1
11	104-691	MOTOR - evaporator fan (two fan see 180D9, three fan see 183B6)	A/R
	77-1498	• BEARING - shaft end	1
	77-1401	• BEARING - opposite end	1
12	41-3593	HARNESS - control box	1
13	45-1927	HEATER (680W, 2 meter leads)	6
14	91-8142	BRACKET - heater (15.4/404 long, MAGNUM)	1
	91-8634	BRACKET - heater (13.6/347 long, MAGNUM SL-40)	1
	92-234	BRACKET - heater (12.3/313 long, MAGNUM SL-40)	1
15	91-8467	BRACKET - heater (13.8/350 long, MAGNUM)	2
	91-8629	BRACKET - heater (12.0 long, MAGNUM SL-40)	2
	92-235	BRACKET - heater (11.4/290 long, MAGNUM SL-20)	2
	51-1447	SCREW - bracket	11
16	41-5103	VALVE - solenoid	1
	41-3301	COIL - valve	1
17	41-3401	THERMOSTAT - defrost termination	1
	51-336	SCREW - thermostat	2
18	102-795	COMPRESSOR - scroll (see 180E1)	1
19	NSS	BOX - control (see 158A3)	1
20	40-782	CABLE - compressor	1
21	41-4004	SWITCH - hpco	1






REF	PART#	DESCRIPTION	QTY
22	61-2057	VALVE - digital	1
	41-7937	• COIL (only)	1
23	41-9220	SENSOR - humidity	1
24	NSS	PANEL - USDA receptacle (see 173B1)	1
	NSS	PANEL - USDA receptacle (see 183B3, SL-40 & 20)	1
25	40-776	KIT - thermistor	1
26	51-270	CONNECTOR - liquid tite	1
27	41-6150	TRANSDUCER - suction (200 psi)	1
28	41-6151	TRANSDUCER - discharge (200 psi)	1






REF	PART#	DESCRIPTION	QTY
1	92-236	BRACKET - diagram	1
	55-3272	RIVET - bracket	4
2	92-237	BRACKET (w/ receptacle)	2
	55-2074	NUT - speed	4
	55-9166	SCREW - bracket	4
	55-9444	WASHER - insulating (nylon)	4
3	45-2010	BOARD - relay (MP3000 A)	1
	845-2010	BOARD - relay (reman, MP3000 A)	1
4	41-7587	• RELAY - power (K24-58162-02)	6
	92-860	• CLIP - relay	6
5	504-970	• FUSE (20A)	3
6	41-9318	• HOLDER - fuse	3
	51-336	SCREW - relay board	6
7	41-3402	CABLE - retriever plug (Deutsch, see download panel grid)	1
	41-2583	CABLE - retriever plug (Cannon, see download panel grid)	1
	55-3272	RIVET - plug	4
	41-2406	CAP - plug	1
	99-3685	CHAIN - cap	1
8	92-238	HINGE - cover	2
	55-7172	SCREW - hinge	4
	51-618	INSULATOR	2
	51-1423	FLATWASHER	4
	51-1424	LOCKWASHER	2
	55-7042	NUT	4
9	55-9346	PLUG - seal	2
10	91-9833	NAMEPLATE - Caution	1
11	91-9272	NAMEPLATE - On/Off	1
12	41-3686	CONNECTOR - liquid tite	1
13	55-5900	FITTING - harness	5
14	55-5257	FITTING - harness	2
15	41-3595	SWITCH - On/Off (unit & cond fan)	2
	92-239	BOOT - switch	1
16	92-5520	BRACKET - battery	1
	55-2988	RIVET - bracket	1
17	41-2832	CONNECTOR - plug (2 pin, short circuit)	1
	41-3596	BLOCK - terminal (4 pole)	1
	41-3597	BLOCK - terminal (5 pole)	1
	41-3598	BLOCK - terminal (8 pole)	1
	41-3851	BLOCK - terminal (12 pole)	1
	41-3599	BLOCK - terminal (14 pole)	1
	41-3608	BLOCK - terminal (18 pole)	1
18	NSS	DOOR - controller (see 183B5 & 188E8)	1






REF	PART#	DESCRIPTION	QTY
19	203-509	BATTERY (12V, 1.9 AH)	1
	55-9759	SCREW - battery	1
	55-6995	FLATWASHER	2
	55-7042	NUT	1
20	33-3837	GASKET - cover	1
21	33-3838	GROMMET	1
22	98-5454	BOX - control	1
	55-6994	SCREW - control box	4
	55-8893	FLATWASHER	4
	55-9054	WASHER - insulator	4
23	33-3215	GROMMET	3
24	NSS	TRAY - high voltage (see 158A1)	1
25	41-3335	CABLE - battery	1
	41-4527	• CONNECTOR (7 pin)	1
	44-6381	• CONNECTOR (2 pin)	2
26	309-3066	RAIL - terminal block	1
	55-7169	SCREW - rail	2
	55-7033	FLATWASHER	2
	51-619	WASHER - insulator	2
	55-7034	NUT	2
27	41-3687	TERMINAL - stop clip	2
28	41-5105	PLATE - end terminal	1
29	41-3688	BLOCK - terminal	6
30	41-3703	CONNECTOR - cross	1
31	44-9359	FUSE (7.5 amp)	1






REF	PART#	DESCRIPTION	QTY
1	92-3445	PLATE - bottom	1
	51-1421	SCREW - plate to box	4
	51-619	WASHER - insulator	4
	51-1464	FLATWASHER	4
	51-1423	LOCKWASHER	4
	51-1425	NUT	4
2	41-5104	BREAKER - circuit (25 amp)	1
3	41-3605	CONTACTOR (CI 25)	2
4	41-3317	TRANSFORMER	1
	55-9396	SCREW - transformer	4
5	91-9914	RAIL - din (60 mm)	1
6	91-9915	RAIL - din (125 mm)	1
7	55-9166	SCREW (pan hd)	11
	55-7370	LOCKWASHER	6
8	41-3604	INTERLOCK	1
9	41-5309	CONTACTOR - auxiliary (4 pin remote option, see 158A5)	2






REF	PART#	DESCRIPTION	QTY
1	98-6784	DOOR - control box (complete, includes 1 thru 6, 8, 9, 10 & 13)	1
	91-9380	• DOOR - control box	1
2	41-4142	• KEYPAD (MP3000)	1
3	91-9381	• HINGE - door	2
	51-1418	• SCREW - hinge	4
	55-9444	• WASHER (nylon)	4
	51-1420	• WASHER	8
	51-1419	• NUT	4
4	55-9392	• INSULATOR - hinge	2
5	55-8919	• RETAINER - screw	2
6	55-9393	• SCREW - door (knurled)	2
	51-1470	SCREW - door (Phillips)	2
7	45-2009	CONTROLLER (MP3000-A)	1
	845-2009	CONTROLLER (reman, MP3000-A)	1
8	44-6777	• FUSE (2 amp)	2
9	41-4919	• DISPLAY - controller	1
10	203-506	• BATTERY - lithium	1
	51-1419	NUT - controller	4
	55-8919	LOCKWASHER	2
	55-9444	WASHER - insulating (nylon)	4
11	41-3602	CABLE - connecting (25 pin, No. 1 & 3)	2
12	41-3603	CABLE - connecting (RMM, option 098158, 098159)	1
13	55-9395	ADAPTER - push-on	1
	51-1419	NUT	1
14	91-9382	NAMEPLATE - Warning, Power Off	1
15	92-3446	NAMEPLATE - Phase Select	1
16	41-2835	CABLE - connecting (No. 2)	1
17	45-1898	MODEM (RMM, option 098158, 098159)	1
	45-1898	MODEM (MPC - 2000, 098983)	1
18	41-3335	CONNECTOR (7 pin)	1
19	92-3554	GASKET - controller	1






REF	PART#	DESCRIPTION	QTY
1	41-2406	CAP - dust (5-pin Deutsch)	1
	99-3685	CHAIN - cap	1
2	204-918	CABLE - data (5-pin Deutsch to 15-pin D connectors)	1
	204-974	CABLE - data (5-pin Cannon bayonet to 15-pin D connectors)	1
	204-975	CABLE - data (5-pin Cannon threaded to 15-pin D)	1
3	44-9417	CABLE - data (15-pin D connector, 9-pin D PC, 20 ft)	1
	44-9418	CABLE - data (15-pin D connector, 9-pin D PC, 50 ft)	1
4	204-1109	ADAPTER - 9-pin D PC connector to USB	1
5	N/A	ADAPTER - 9-pin D PC to PC card (see service bulletin C061)	1
6	41-8065	CABLE - data download	1
7	41-3588	CAP - dust (5-pin Cannon)	1






REF	PART#	DESCRIPTION	QTY
1	45-1859	TRANSFORMER	1
2	41-1977	RECEPTACLE - power (32 amp, 440V)	1
	55-2995	• SCREW - receptacle	4
	55-2964	• LOCKWASHER	2
	55-2001	• FLATWASHER	2
3	55-5919	• CONNECTOR - grip	1
	55-2636	• NUT - connector	1
4	41-3083	• CABLE - power (69 ft)	1
5	91-9508	INSULATOR	2
6	55-7341	SCREW - transformer	2
	55-8891	SCREW - transformer	4
	55-7085	FLATWASHER	6
	55-7342	LOCKWASHER	6
7	91-6988	BRACKET - cable restraint (current units)	1
8	55-9164	SCREW - cable	1
	55-7357	FLATWASHER	1
	55-7344	NUT	1
9	55-7172	SCREW - bracket	4
	55-7075	FLATWASHER	4
	55-7170	LOCKWASHER	4
10	91-3238	BRACKET - cable (early units)	1
	55-7172	SCREW - bracket	3
	55-6995	FLATWASHER	6
	55-7042	NUT	3
11	44-3828	PLUG - power (50 amp)	1
	44-5133	PLUG - power (60 amp, orange)	1
	41-3429	PLUG - power (50 amp, blue)	1
	33-2482	BUSHING - plug	1





REF	PART#	DESCRIPTION	QTY
1	45-1830	THERMOMETER - recording (31 day, Partlow, 098025, see 147B2)	1
	45-1831	THERMOMETER - recording (31 day, Saginomiya, battery, 098026, see 147B9)	1
	45-1832	THERMOMETER - recording (31 day, Saginomiya, AC power, 098030, see 147B9)	1
	55-7172	SCREW - recorder	4
	55-6996	LOCKWASHER	4
	55-6995	FLATWASHER	4
2	91-8705	BOX - recorder	1
	55-7341	SCREW - box	4
	55-6988	FLATWASHER	4
	55-8953	WASHER (nylon)	4
3	91-4218	PLATE - box (bottom)	1
	55-7340	SCREW - plate	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
4	33-451	GROMMET	1
5	99-7230	GUIDE - latch	1
6	55-7169	SCREW - guide (12 mm)	1
7	55-8720	SCREW - guide (25 mm)	1
8	55-7033	FLATWASHER	4
9	55-7464	LOCKWASHER	1
10	55-9444	WASHER - insulating (nylon)	4
11	55-7034	NUT	4
12	91-5005	LATCH - cover	1
	55-2988	RIVET - latch	2
13	91-5006	BRACKET - latch	1
	55-7340	SCREW - bracket	2
	55-7033	FLATWASHER	4
	55-7404	LOCKWASHER	2
	55-7354	NUT	2
14	98-5532	COVER - recorder (includes 15, 16 & 17)	1
15	91-5007	• PLATE - keeper	1
	55-2988	• RIVET - plate	2
16	91-8707	• WINDOW	1
17	33-3008	• GASKET - cover	4
	91-4219	HINGE SET - left	1
18	91-8708	• HINGE - right (w/ pin)	1
19	91-8725	• HINGE - right (w/o pin)	1
20	91-8709	• HINGE - left (w/ pin)	1




Revised
7/31/11

**RECORDING THERMOMETER (OPTION 098026 &
098030)**




147B8

REF	PART#	DESCRIPTION	QTY
21	91-8726	• HINGE - left (w/o pin)	1
	55-7169	SCREW - hinge	8
	55-7033	FLATWASHER	8
	55-7404	LOCKWASHER	8
	91-4220	HINGE SET - right	1
22	203-180	CHART (31 day, -20 to +80 F, box of 50)	1
	203-252	CHART (31 day, -30 to +25 C, box of 50)	1
	203-219	CHART (31 day, -25 to +25 C, box of 50)	1






REF	PART#	DESCRIPTION	QTY
	45-1830	THERMOMETER (31 day, F)	1
1	44-5644	• ELEMENT - thermo (1/2 od, 7.5 in lg bulb, 10 ft capillary)	1
	44-2339	• ELEMENT - thermo (3/8 od, 14 in lg bulb, 10 ft capillary)	1
2	91-8217	• ROD - push	1
3	33-2962	• O-RING	1
4	41-2216	• MECHANISM	1
5	44-2966	• DRIVE - chart (31 day)	1
6	91-2209	• NUT, CLIP & CORD	1
7	41-2218	• PLATEN	1
8	55-8955	• KEY - winding	1
9	91-2205	• KIT - stylus	1
10	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1






REF	PART#	DESCRIPTION	QTY
	45-1831	THERMOMETER - recording (Saginomiya, 31 day battery)	1
	45-1832	THERMOMETER - recording (Saginomiya, 31 day, AC power)	1
1	44-9780	• ELEMENT	1
2	44-9781	• INDICATOR - volt	1
3	44-7782	• TIMER	1
4	91-4380	• PLATE - recorder	1
5	505-390	• NUT - chart	1
6	41-4382	ARM - pen lift	1
7	203-180	CHART (31 day, -20 to +85 Fahrenheit, box of 50)	1
	203-252	CHART (31 day, -30 to +25 C, box of 50)	1
	203-219	CHART (31 day, -25 to +25 C, box of 50)	1





REF	PART#	DESCRIPTION	QTY
	45-2318	THERMOMETER & BOX ASSEMBLY	1
1	45-2012	• THERMOMETER - recording (31 day)	1
	55-7172	• SCREW - recorder	4
	55-7170	• LOCKWASHER	4
	55-7075	• FLATWASHER	4
2	91-8705	• BOX - recorder	1
	55-7341	• SCREW - box	4
	55-6988	• FLATWASHER	4
	55-8953	• WASHER - insulating	4
3	92-5547	• PLATE - box (bottom)	1
4	91-5006	• BRACKET - latch	1
	55-7036	• SCREW - plate	2
	55-7033	• FLATWASHER	4
	55-7404	• LOCKWASHER	2
	55-7354	• NUT	2
5	99-7230	• GUIDE - latch	1
6	55-9002	• SCREW - guide (30 mm)	1
7	55-7340	• SCREW - guide (16 mm)	1
8	55-7033	• FLATWASHER	4
9	55-9054	• LOCKWASHER	1
10	55-9444	• WASHER - insulating	4
11	55-7034	• NUT	4
12	91-5005	• LATCH - cover	1
	55-2988	• RIVET - latch	2
13	33-367	• GROMMET	1
	55-7354	• NUT	2
14	98-5532	• COVER - recorder (includes 15, 16 & 17)	1
15	91-5007	•• PLATE - keeper	1
	55-2988	•• RIVET - plate	2
16	91-8707	•• WINDOW	1
17	99-7849	•• GASKET - cover	4
18	91-8708	• HINGE - right (w/ pin)	1
19	91-8725	• HINGE - right (w/o pin)	1
20	91-8709	• HINGE - left (w/ pin)	1
21	91-8726	• HINGE - left (w/o pin)	1
	55-7340	• SCREW - hinge	8
	55-7033	• FLATWASHER	8




Revised
12/25/10

ELECTRONIC CHART RECORDER



212G9

REF	PART#	DESCRIPTION	QTY
	55-7404	• LOCKWASHER	8
22	203-546	CHART - thermometer (31 day)	1




Revised
2/25/04

**REMOTE MONITOR OPTION (098182 CSR; 098144
CRR; 098182 CSR)**




158A5

REF	PART#	DESCRIPTION	QTY
1	41-3606	HARNESS - remote monitor	1
2	41-3607	• RECEPTACLE (4 pin)	1
	55-9322	RIVET - receptacle	4
3	92-206	CAP - plug	1
	55-9323	RIVET - cap	1
4	41-5309	CONTACTOR - auxiliary (CSR units)	2






REF	PART#	DESCRIPTION	QTY
	41-3336	PANEL - USDA, assembly	1
1	91-9834	• PANEL - USDA receptacle	1
2	41-3585	• CONNECTOR (12 pin)	1
3	41-3586	• RECEPTACLE (5 pin, cannon, bayonet)	1
4	41-3587	• RECEPTACLE (4 pin, cannon, bayonet)	3
	55-9322	• RIVET - receptacle	16
5	41-3588	• CAP - receptacle	4
	55-3272	• RIVET - cap	4
6	92-206	• CAP - plug	1
	55-9211	RIVET - panel	4
7	41-5405	SENSOR - PT100 (4 pin, cannon, bayonet)	4
8	41-2853	CABLE & PLUG - retriever (cannon threaded)	1






REF	PART#	DESCRIPTION	QTY
1	91-9834	PANEL - USDA receptacle (before 4/00)	1
	92-428	PANEL - USDA receptacle (4/00 & after)	1
	55-3272	RIVET - panel	4
2	41-2406	CAP - dust	1
3	99-3685	CHAIN - cap	1
4	41-3588	CAP - dust	3
	55-9322	RIVET - cap	4
5	304-2772	RECEPTACLE (3 pin, Deutsch)	3
	55-9322	RIVET - connector	16
6	41-2405	RECEPTACLE (5 pin, Deutsch)	1
7	55-9402	PLUG - spare hole	1
8	41-3585	CONNECTOR - plug (12 pin)	1
9	92-243	NAMEPLATE - data download USDA	1
10	41-8188	SENSOR (3 pin, Deutsch, 14 m, NTC)	4
11	41-3402	CABLE & PLUG - retriever (Deutsch)	1






REF	PART#	DESCRIPTION	QTY
1	92-428	PANEL - USDA receptacle	1
	51-1448	RIVET - panel	4
2	41-2406	CAP - dust	1
3	99-3685	CHAIN - cap	1
4	41-3588	CAP - dust	4
	55-9323	RIVET - cap	5
5	41-3587	RECEPTACLE (4 pin, Deutsch)	4
	55-9322	RIVET - connector	16
6	41-5416	CONNECTOR - plug (16 pin)	1
7	92-243	NAMEPLATE - data download (USDA)	1
8	41-8188	SENSOR (3 pin, Deutsch, 14 m, NTC)	4
9	41-3402	CABLE & PLUG - retriever (Deutsch)	1





REF	PART#	DESCRIPTION	QTY
1	91-8195	KEEPER - door latch	2
	51-1459	SCREW - keeper	4
	51-1464	WASHER	4
	55-9054	WASHER (vinyl)	4
2	91-8108	BRACKET - frame	1
	51-1442	SCREW - bracket	5
	51-1464	FLATWASHER	5
	55-9054	WASHER (nylon)	5
	51-1425	NUT	3
3	98-6236	PLATE - cable storage (units w/ water cooled cond)	1
	98-6560	PLATE - cable storage (units w/o water cooled cond)	1
	51-1425	NUT	2
	55-9054	WASHER (nylon)	4
	51-1464	FLATWASHER	4
4	91-8474	PLATE - guard	1
	55-7341	SCREW - plate	3
	51-1464	FLATWASHER	6
	55-9054	WASHER - insulation	6
	55-7339	NUT	3
5	98-5925	GRILLE - condenser (see 189C4)	1
	33-3043	GASKET - rubber extrusion	1
	51-1445	SCREW - grille	4
	51-1464	FLATWASHER	4
	55-9054	WASHER (nylon)	4
6	98-6518	DOOR - evaporator (hinged door, blot-on door see 226E3)	1
	98-7430	DOOR - evaporator (Transfresh, see 212G0)	1
7	91-9040	• KNOB	2
8	51-1460	• SCREW - door (TIR seal)	2
9	91-8199	• SPRING	2
10	55-7354	• NUT	2
11	51-619	• WASHER (nylon)	2
12	91-9041	• LATCH - door	2
	55-3101	• RIVET - latch	4
13	91-8134	• INSULATOR - latch	2
14	91-9039	• HOOK - strap	1
15	509-937	• STRAP - door	1
	51-801	• SCREW - strap	1
	55-8893	• FLATWASHER	2
16	91-8256	• PIN - hinge (w/snap)	2
17	509-1654	• HINGE - frame	2






REF	PART#	DESCRIPTION	QTY
	51-1460	SCREW - hinge (TIR seal)	4
	55-9541	WASHER (nylon)	4
18	33-3969	GASKET - evaporator door	1
19	91-8475	NAMEPLATE - TK	1
20	33-2983	GASKET - unit	1
21	91-8728	COVER (instead of thermometer)	1
	51-1467	SCREW - cover	3
	55-6988	FLATWASHER	3
22	92-891	BRACKET - safety hook	1
	55-6993	SCREW - bracket	4
	55-7085	FLATWASHER	8
	55-9541	WASHER (nylon)	8
23	98-6771	FRAME - condenser (Maersk, WCC)	1
	98-7418	FRAME - condenser (w/ nitrogen ports)	1
	98-7410	FRAME - condenser (WCC)	1
	98-7424	FRAME - condenser	1
	98-7446	FRAME - condenser (Transfresh)	1
24	91-9754	POCKET - sensor	2
25	91-9949	PORT - injection (optional)	2
	51-1448	RIVET - port	4
26	91-9950	HOUSING - relief valve	1
	51-1448	RIVET - housing	4
27	91-9951	VALVE - pressure relief	1
28	61-2271	VALVE - vacuum (before 11/05)	1
	61-5619	VALVE - vacuum (11/05 & after)	1

**CONDENSER COMPONENTS (20 ft CONTAINER,
THREE FANS)**



183B7

REF	PART#	DESCRIPTION	QTY
1	91-8195	KEEPER - door latch	3
	55-9312	SCREW - keeper (TIR seal)	6
	55-6995	WASHER	6
	55-9054	WASHER (nylon)	6
	55-8877	WASHER (nylon)	6
2	91-8108	BRACKET - frame	1
	55-6993	SCREW - bracket	3
	55-6988	WASHER	6
	55-9541	WASHER (nylon)	6
	55-9380	NUT	3
3	91-6560	PLATE - cable storage (front)	1
	55-9168	NUT	2
	55-9054	WASHER (nylon)	6
	55-6994	SCREW - plate	2
	55-6695	FLATWASHER	6
	55-8933	WASHER (nylon)	6
4	91-8474	PLATE - guard	1
	55-7341	SCREW - plate (20 mm)	2
	55-6993	SCREW - plate (25 mm)	2
	55-7339	NUT	6
	55-8904	FLATWASHER	6
	55-8953	WASHER - insulation	6
5	98-5925	GRILLE - condenser	1
	55-6994	SCREW - grille	4
	55-6995	FLATWASHER	4
	55-9054	WASHER (nylon)	4
6	509-755	DOOR - evaporator	1
	92-2995	HINGE - evap door	3
	51-620	RIVET - hinge	12
7	91-9040	KNOB	3
8	55-7035	SCREW - door	3
9	91-8199	SPRING	3
10	55-7354	NUT	3
11	55-9054	WASHER (nylon)	3
12	91-9041	LATCH - door	3
	55-2864	RIVET - latch	6
13	91-8134	INSULATOR - latch	3
14	509-1654	HINGE	3
	55-9313	SCREW - hinge (TIR seal)	6
	55-9541	WASHER (nylon)	6
15	91-8256	PIN - hinge (w/ snap)	3
16	92-891	BRACKET - safety hook	1




**CONDENSER COMPONENTS (20 ft CONTAINER,
THREE FANS)**




183B7

REF	PART#	DESCRIPTION	QTY
	55-6993	SCREW - bracket	4
	55-7085	WASHER	8
	55-9541	WASHER (nylon)	8
17	98-6563	FRAME - condenser	1
18	33-3968	GASKET - evaporator door	1
19	91-9511	NAMEPLATE - TK	1
20	33-2983	GASKET - unit	1
21	91-8728	COVER (instead of thermometer)	1
	55-7391	SCREW - cover	3
	55-6988	FLATWASHER	3
22	91-9039	HOOK - strap	1
	55-3065	CLAMP - hook	1
	55-9166	SCREW - clamp	1
23	509-937	STRAP - door	1
	55-9173	SCREW - strap	1
	55-7089	FLATWASHER	2
24	91-9754	POCKET - sensor	2






REF	PART#	DESCRIPTION	QTY
1	98-7691	DOOR - evaporator (bolt-on door)	1
	51-1460	SCREW - door (M8, TIR seal)	4
	51-1430	FLATWASHER (M8)	4
	55-9541	WASHER (M8, nylon)	4
	51-1459	SCREW - door (M6, TIR seal)	4
	51-1464	FLATWASHER (M6)	4
	55-9054	WASHER (M6, nylon)	4
2	33-3969	GASKET - evaporator door	1
3	91-8728	COVER (instead of thermometer)	1
	51-1467	SCREW - cover	3
	51-1444	FLATWASHER	3
4	98-5925	GRILLE - condenser (see 189C4)	1
	33-3043	GASKET - rubber extrusion	1
	51-1445	SCREW - grille	4
	51-1464	FLATWASHER	4
	55-9054	WASHER (nylon)	4
5	91-8475	NAMEPLATE - TK	1
6	91-8474	PLATE - guard	1
	55-7341	SCREW - plate	3
	51-1464	FLATWASHER	6
	55-9054	WASHER - insulation	6
	55-7339	NUT	3
7	98-6560	PLATE - cable storage (units w/o water cooled cond)	1
	98-6236	PLATE - cable storage (units w/ water cooled cond)	1
	51-1425	NUT	2
	55-9054	WASHER (nylon)	4
	51-1464	FLATWASHER	4
8	91-8108	BRACKET - frame	1
	51-1442	SCREW - bracket	5
	51-1425	NUT	3
	55-9054	WASHER (nylon)	5
	51-1464	FLATWASHER	5
9	92-891	BRACKET - safety hook	1
	51-1443	SCREW - bracket	4
	51-1430	FLATWASHER	4
	55-9541	WASHER (nylon)	4
10	33-2983	GASKET - unit	1
11	98-7424	FRAME - condenser	1
	98-7410	FRAME - condenser (WCC)	1
	98-7446	FRAME - condenser (Transfresh)	1
	98-7418	FRAME - condenser (w/ nitrogen ports)	1
	98-6771	FRAME - condenser (Maersk, WCC)	1






REF	PART#	DESCRIPTION	QTY
12	91-9754	POCKET - sensor	2
13	91-9949	PORT - injection (optional)	2
	51-1448	RIVET - port	4
14	91-9950	HOUSING - relief valve	1
	51-1448	RIVET - housing	4
15	91-9951	VALVE - pressure relief	1
16	61-2271	VALVE - vacuum (before 11/05)	1
	61-5619	VALVE - vacuum (11/05 & after)	1
17	33-4829	GASKET - door	4






REF	PART#	DESCRIPTION	QTY
	91-8252	VENT - air (complete)	1
1	91-9048	• BRACKET - air vent handle	1
2	51-1426	• SCREW - handle	1
	51-1474	• SCREW (M8 x 1.25 x 65, ss)	1
	55-9541	• WASHER (nylon)	4
	51-1427	• NUT	1
3	91-8100	• SPRING	1
4	92-440	• NAMEPLATE - Do Not Open Below 0 C	1
5	91-8102	• HANDLE - air vent	1
6	77-2467	• BEARING - slide	1
7	91-8104	• BRACKET - handle	1
8	51-1428	• NUT	2
	51-1429	• LOCKWASHER	1
	51-1430	• FLATWASHER	1
9	51-1431	• NUT - wing	1
10	91-8103	DISK - air vent	1
11	33-4255	• GASKET - air vent	1
12	91-8105	• PLATE - air vent	1
	55-7172	• SCREW - plate	4
	55-7075	• FLATWASHER	4
	55-9541	• WASHER (nylon)	4
13	33-2944	• GASKET - air vent	1
14	91-8663	• PROTECTOR - edge	1
15	91-8106	• PIN - hinge	1
16	91-8107	• NAMEPLATE - Do Not Open Below 0 C	1
17	55-9168	• ADAPTER - hose	1
18	92-411	• HINGE - air vent	1
	51-619	SCREW - vent	8
	55-8933	WASHER - insulator (6.4 id)	4
	55-7075	FLATWASHER	4
	55-9054	WASHER - insulator (8.4 id)	6
	55-8893	FLATWASHER	6
	55-7339	NUT	6






REF	PART#	DESCRIPTION	QTY
1	91-9048	BRACKET - air vent handle	1
2	55-9442	SCREW - handle	1
	55-9541	WASHER - insulation	4
	51-1427	NUT	1
3	91-8100	SPRING	1
4	41-5666	DEVICE - door position sensor	1
5	91-8102	HANDLE - air vent	1
6	51-1458	SCREW - disk	1
7	91-8104	BRACKET - handle	1
8	51-1211	NUT	2
	51-1429	LOCKWASHER	1
	51-1430	FLATWASHER	1
	55-9541	WASHER - insulating	3
9	51-1431	NUT - wing	1
10	91-8103	DISK - air vent	1
11	33-4255	GASKET - air vent	1
12	509-753	PLATE - air vent	1
	55-7172	SCREW - plate	4
	55-7075	FLATWASHER	4
	55-8877	WASHER (nylon)	4
13	33-2944	GASKET - air vent	1
14	91-8663	PROTECTOR - edge	1
15	91-8106	PIN - hinge	1
16	92-440	NAMEPLATE - Do Not Open Below 0 C	1
17	55-9168	ADAPTER - hose	1
18	92-411	HINGE - air vent	1
	55-6994	SCREW - vent hinge	8
	55-8893	FLATWASHER	4
	55-9541	WASHER - insulator (8.4 id)	6
	55-7339	NUT	6






REF	PART#	DESCRIPTION	QTY
1	55-7349	SCREW - air vent	1
2	92-240	PLATE - air vent	1
3	33-3214	• GASKET - air vent	1
	55-7172	SCREW	6
	55-7075	FLATWASHER	6
	55-8877	WASHER (nylon)	6
4	92-241	LABEL - air ventilation	1
5	91-8103	DISK - air vent	1
6	33-2967	• GASKET	1
7	55-7342	LOCKWASHER	1
8	55-7825	NUT	2
9	92-242	BEARING - slide	1
10	55-7085	FLATWASHER	1
11	55-8888	NUT - wing	1
12	55-9168	BARB - hose adapter	1
13	55-8886	WASHER (nylon)	1






REF	PART#	DESCRIPTION	QTY
1	92-412	BRACKET - motor box	1
	55-7172	SCREW - bracket	2
	55-8893	FLATWASHER	2
	51-619	WASHER - insulator	2
2	92-415	GRILLE - fresh air	1
	55-7172	SCREW - grille	3
	55-8893	FLATWASHER	3
	51-619	WASHER - insulator	3
3	92-416	BRACKET - receptacle	1
	55-7172	SCREW - bracket	2
4	33-3264	GASKET - receptacle (10 x 10)	1
5	92-414	HOUSING - motor	1
	55-7404	LOCKWASHER	4
	55-7033	FLATWASHER	4
	55-7367	NUT	4
6	33-314	GROMMET	1
7	92-413	BRACKET - mechanical stop	1
	55-7862	SCREW - bracket	4
	203-393	SEALER - thread	A/R
8	41-3674	MOTOR - damper (24VDC)	1
9	41-2832	CONNECTOR - plug (2 pin)	1
10	92-418	LINKAGE	1
11	92-417	LINKAGE	1
	55-7027	SCREW - linkage	2
	55-8893	WASHER	4
	55-7042	NUT	2
12	55-3537	PIN - cotter	2
13	55-9338	WASHER - shoulder	1
14	92-419	ROD - linkage	1
15	11-4929	BALL JOINT	1
	92-5521	BALL JOINT	1
16	55-9437	RETAINER - pin	1
17	92-420	VENT - air	1
18	33-3265	GASKET - air vent	1
19	92-411	HINGE - plate	1
20	91-8106	PIN - hinge (w/ snap)	1
21	41-3583	BOARD - interface (AFAM+)	1
22	41-3584	CABLE - AFAM/AFAM+	1






REF	PART#	DESCRIPTION	QTY
1	92-5685	BRACKET - air vent	1
	55-6994	SCREW - bracket	2
	51-619	WASHER - insulator	2
	55-8893	FLATWASHER	2
2	33-3264	GASKET	1
3	92-5686	BRACKET - rear	1
	51-1445	SCREW - bracket	2
	51-1464	FLATWASHER	2
	55-9054	WASHER - insulator	2
4	51-1496	PIN - clevis	2
5	77-2870	BEARING	4
6	55-2550	PIN - cotter	2
7	41-7238	ACTUATOR	1
8	92-5687	DOOR - AFAM	1
9	91-8106	PIN - hinge	1
10	33-3265	GASKET - air vent	1
11	92-416	BRACKET - grille	1
	51-1445	SCREW - bracket	2
	55-9054	WASHER - insulator	2
	51-1464	FLATWASHER	2
12	92-415	GRILLE - fresh air	1
	51-1422	SCREW - grille	3
	41-1441	FLATWASHER	3
	51-619	WASHER - insulator	3
13	41-3583	BOARD - interface	1
14	41-3584	CABLE - AFAM/AFAM+	1
15	92-5201	LABEL - AFAM door position	1






REF	PART#	DESCRIPTION	QTY
1	98-5773	PLATE - rear (bottom)	1
2	98-5772	PLATE - rear (top)	1
	51-336	SCREW - plate	23
	55-9444	WASHER - insulating	23
	55-3136	RIVET - plate	29
3	98-5774	GRILLE - evaporator (MAGNUM)	1
	98-5923	GRILLE - evaporator (MAGNUM 924)	1
	98-6556	GRILLE - evaporator (MAGNUM 40-SL)	1
	98-6565	GRILLE - evaporator (MAGNUM 20)	1
	55-3136	RIVET - grille	17
4	92-427	CHANNEL - Z (100 mm deep)	5
	92-2774	CHANNEL - Z (57 mm deep)	5
	91-9922	CHANNEL - Z (MAGNUM 20)	5
	51-621	RIVET - channel	39
5	NSS	PANEL - USDA receptacle (see 157H2 & 189D7)	1
6	92-2773	CHANNEL - air (MAGNUM)	1
	91-9923	CHANNEL - air (MAGNUM SL 40 & 20)	1
	203-389	SEALER - polyurethane (white)	A/R
	55-8891	SCREW - channel	6
7	91-9330	INLET - fresh air (MAGNUM)	1
	91-9924	INLET - fresh air (MAGNUM SL 40 & 20)	1
	55-9323	RIVET - inlet	10
	203-389	SEALER - polyurethane (white)	A/R
8	91-9331	CHANNEL - fresh air	1
	55-9323	RIVET - channel	8
9	98-5775	PLATE - cover (Transfresh)	1
	55-7713	RIVET - plate	4
10	41-2554	CABLE - Transfresh (option 098150)	1
11	41-2555	CABLE - Transfresh (option 098150)	1
12	41-5405	SENSOR - PT100 (option 098106)	2
13	92-722	PLATE - cover	1
	55-2262	RIVET - plate	6






REF	PART#	DESCRIPTION	QTY
1	91-8244	BRACKET - hose	1
2	99-3281	MOUNT - cable tie	5
	55-2260	RIVET - mount	5
3	55-2686	CLAMP - hose	2
4	55-8891	SCREW - bracket	2
5	55-9208	CONNECTOR - T (hose)	1
6	55-2330	BANDWRAP	6
7	11-8983	HOSE - flex	1
8	11-9575	T-DRAIN	1
	11-9735	T-DRAIN (after 9/03)	1
9	11-9576	HOSE - flex (11/01 & after)	A/R





REF	PART#	DESCRIPTION	QTY
1	98-5925	GRILLE - condenser	1
	51-1445	SCREW - grille	4
	51-1464	FLATWASHER	4
	55-9054	WASHER (nylon)	4
2	33-3043	GASKET - grille (extrusion)	1
3	11-9734	HOSE - drain (29 mm id, cut as required)	A/R
4	55-2330	BANDWRAP	A/R
5	11-9735	TEE - drain hose	1
6	11-9576	HOSE - drain (21 mm id, cut as required)	A/R



1




Ingersoll-Rand

2

THERMO KING

3

WARNING
Hot Components
Compressor discharge
may be hot!



7

R-404A
COMPRESSOR FILLED WITH ESTER OIL
PART No.: 203-433

4

WARNING
FANS START
AUTOMATICALLY

5

WARNING !
TURN POWER OFF
BEFORE DISCONNECTING
DATALOGGER OR
CONTROLLER.

6

8

DATA DOWNLOAD PORT

USDA #1/
SPARE 1

USDA #2/
SPARE 2

USDA #3/
SPARE 3

PULP/
SPARE 5

WARNING
CONSULT MAINTENANCE MANUAL FOR
PRECAUTIONS BEFORE WELDING
ON CONTAINER OR REFRIGERATION UNIT.

1. Disconnect all power to the refrigeration unit.
2. Disconnect all quick-disconnect wire harnesses.
3. Switch all of the electrical circuit breakers in the control box to the OFF position.
4. Weld unit and/or container per normal welding procedures. Keep ground return electrode as close to the area to be welded as practical. This will reduce the likelihood of stray welding currents passing through any electrical or electronic circuits.
5. When the welding operation is completed, the unit power cables, wiring and circuit breakers must be restored to their normal condition.

10

**TRANSFRESH
DATA
CONNECTOR
A 3**

11

**TRANSFRESH
SCRUBBER
CONNECTOR
A 5**

12

WARNING Make sure container is vented before entering, may contain low oxygen condition.

WARNING Vergewissern Sie sich, dass der Container vor dem Eintreten belüftet ist, um Sauerstoffmangel auszuschließen!

ADVERTENCIA Cerciórese de que el contenedor sea ventilado antes de entrar. Puede encontrarse en condiciones de poco oxígeno.

주의 들어가기 전에 컨테이너에 공기가 되었는지 확인하십시오. 저산소 상태가 발생할 수 있습니다.

警告 入る前にコンテナに換気し、たかどきが確認して下さい。低酸素状態になるおそれがあります。

14

WARNING

Do Not Operate Scroll Compressor with Service or Receiver Tank Valves Closed. Compressor Damage Will Occur.

13


DO NOT OPEN BELOW 0°C 32°F

150 m³/h
90 CFM
55%

225 m³/h
135 CFM
80%

280 m³/h
165 CFM
100%

15



16

DOOR POSITION

CLOSED

1

2

3

4

5

6

#	CMH	CFM
1	35	21
2	75	45
3	125	75
4	150	90
5	225	135
6	280	165

17

WARNING

HOT COMPONENTS
Compressor Discharge may be hot.

Do not operate compressor with service valves closed. Compressor damage will occur.

18



REF	PART#	DESCRIPTION	QTY
1	91-8475	NAMEPLATE - TK (crest)	1
2	92-4305	NAMEPLATE - IR logo (red/black)	1
3	91-9778	NAMEPLATE - Thermo King	1
4	91-8154	NAMEPLATE - R404A	1
5	91-8694	NAMEPLATE - Warning, Fan Start	1
6	91-8695	NAMEPLATE - Warning, Hot Components	1
7	91-5635	NAMEPLATE - Temperature Conversion	1
8	91-9382	NAMEPLATE - Warning	1
9	92-243	NAMEPLATE - USDA Connections	1
	92-5392	NAMEPLATE - USDA Connections	1
10	92-1218	NAMEPLATE - Weld	1
11	91-8697	NAMEPLATE - Data A3	1
12	91-8696	NAMEPLATE - Scrubber A5	1
13	91-9596	NAMEPLATE - Warning, Scroll Compressor	1
14	92-2585	NAMEPLATE - Warning, Low Oxygen	1
15	92-440	NAMEPLATE - Air Vent Handle	1
16	91-9831	NAMEPLATE - Air Vent Door	1
17	92-2586	NAMEPLATE - AFAM Door Position	1
18	92-4724	NAMEPLATE - Warning English	1

INDEX NUMERICAL BY PART NUMBER

102-795	14, 18, 24, 28, 34	40-776	28, 36	41-4527	40
104-691	8, 12, 34	40-779	28	41-4919	44
104-759	6, 34	40-782	28, 34	41-5103	14, 34
11-4367	10	40-791	34	41-5104	42
11-4929	88	41-1441	90	41-5105	40
11-8983	94	41-1976	34	41-5309	42, 62
11-9575	94	41-1977	48	41-5405	64, 92
11-9576	94, 96	41-2216	54	41-5416	68
11-9734	96	41-2218	54	41-5460	20, 24
11-9735	94, 96	41-2405	66	41-5666	84
203-180	52, 54, 56	41-2406	38, 46, 66, 68	41-6150	22, 26, 36
203-219	52, 56	41-2554	92	41-6151	22, 26, 36
203-252	52, 56	41-2555	92	41-7238	90
203-385	30	41-2583	38	41-7587	38
203-389	92	41-2832	38, 88	41-7937	16, 20, 26, 36
203-393	28, 30, 88	41-2835	44	41-8065	46
203-454	18	41-2838	34	41-8188	66, 68
203-506	44	41-2853	64	41-9220	36
203-509	40	41-2953	6, 34	41-9318	38
203-516	28	41-3083	48	41-9490	10
203-546	60	41-3301	14, 34	41-9768	10
204-1109	46	41-3317	42	44-2339	54
204-918	46	41-3335	40, 44	44-2966	54
204-974	46	41-3336	64	44-3828	48
204-975	46	41-3401	34	44-4051	34
304-2772	66	41-3402	38, 66, 68	44-5133	48
309-3066	40	41-3429	48	44-5644	54
33-2482	48	41-3583	88, 90	44-6381	40
33-2805	28	41-3584	88, 90	44-6777	44
33-2944	82, 84	41-3585	64, 66	44-7782	56
33-2946	8, 12	41-3586	64	44-9359	40
33-2950	6	41-3587	64, 68	44-9417	46
33-2951	28	41-3588	46, 64, 66, 68	44-9418	46
33-2962	54	41-3593	34	44-9780	56
33-2967	86	41-3595	38	44-9781	56
33-2979	28	41-3596	38	44-9891	34
33-2983	72, 76, 78	41-3597	38	45-1830	50, 54
33-3007	14, 18, 30	41-3598	38	45-1831	50, 56
33-3008	50	41-3599	38	45-1832	50, 56
33-3043	70, 78, 96	41-3602	44	45-1859	48
33-3044	8	41-3603	44	45-1898	44
33-314	88	41-3604	42	45-1927	34
33-3212	32	41-3605	42	45-1992	34
33-3214	86	41-3606	62	45-2009	44
33-3215	8, 12, 40	41-3607	62	45-2010	38
33-3264	88, 90	41-3608	38	45-2012	58
33-3265	88, 90	41-3674	88	45-2318	58
33-367	6, 8, 12, 58	41-3685	8, 34	45-237	34
33-3837	40	41-3686	38	504-970	38
33-3838	10, 12, 40	41-3687	40	505-390	56
33-3912	18, 24	41-3688	40	506-364	14, 18, 30
33-3968	76	41-3703	40	509-1654	70, 74
33-3969	72, 78	41-3851	38	509-753	84
33-4255	82, 84	41-4002	12, 34	509-755	74
33-451	50	41-4004	28, 34	509-937	70, 76
33-4829	80	41-4018	8	51-1211	84
33-566	16, 20, 26	41-4142	44	51-1418	44
33-727	28	41-4382	56	51-1419	44
33-768	32	41-4473	16, 20, 26, 34	51-1420	44

INDEX NUMERICAL BY PART NUMBER

51-1421	42	55-2964	48	55-8316	14, 18, 20
51-1422	90	55-2988	38, 50, 58	55-8382	32
51-1423	38, 42	55-2995	48	55-8464	18
51-1424	38	55-302	14	55-8720	50
51-1425	24, 42, 70, 78	55-3065	76	55-8805	12
51-1426	82	55-3101	70	55-8872	12
51-1427	6, 82, 84	55-3136	92	55-8877	8, 74, 84, 86
51-1428	82	55-3251	14, 18, 24	55-8886	86
51-1429	6, 8, 28, 30, 82, 84	55-3272	38, 64, 66	55-8888	86
51-1430	30, 78, 82, 84	55-3364	28	55-8891	8, 12, 48, 92, 94
51-1431	82, 84	55-3537	88	55-8893	14, 18, 30, 40, 70, 82, 84, 88, 90
51-1432	28	55-4390	14, 18, 24	55-8903	12
51-1433	28	55-5257	38	55-8904	12, 74
51-1434	28	55-5900	6, 8, 38	55-8907	12
51-1435	28	55-5919	48	55-8908	12
51-1436	28	55-6388	16, 20, 22, 24	55-8915	16, 20, 22
51-1437	28	55-6695	74	55-8919	44
51-1438	28	55-6730	18, 30	55-8933	74, 82
51-1439	24	55-6988	12, 16, 50, 58, 72, 74, 76	55-8950	14, 20, 24
51-1440	24	55-6993	8, 12, 16, 72, 74, 76	55-8951	14, 20, 24
51-1441	24, 34	55-6994	14, 40, 74, 84, 90	55-8953	50, 58, 74
51-1442	6, 26, 70, 78	55-6995	40, 48, 50, 74	55-8955	54
51-1443	6, 8, 78	55-6996	50	55-8986	12
51-1444	6, 8, 78	55-7027	16, 88	55-8993	16, 22
51-1445	34, 70, 78, 90, 96	55-7029	16, 22	55-8994	28
51-1446	34	55-7033	40, 50, 52, 58, 88	55-8995	28
51-1447	34	55-7034	40, 50, 58	55-9002	58
51-1448	68, 72, 80	55-7035	8, 14, 30, 74	55-9012	28
51-1458	84	55-7036	58	55-9013	28
51-1459	70, 78	55-7042	14, 18, 20, 38, 40, 48, 88	55-9027	16, 18, 22
51-1460	70, 72, 78	55-7066	8, 12	55-9054	6, 14, 18, 26, 34, 40, 58, 70, 74, 78, 82, 90, 96
51-1462	30	55-7075	8, 12, 14, 16, 18, 20, 48, 58, 82, 84, 86	55-9086	32
51-1464	26, 42, 70, 78, 90, 96	55-7085	8, 48, 72, 76, 86	55-9162	8
51-1467	30, 72, 78	55-7089	76	55-9164	48
51-1470	44	55-7169	40, 50, 52	55-9166	38, 42, 76
51-1474	82	55-7170	48, 58	55-9168	74, 82, 84, 86
51-1496	90	55-7172	8, 12, 38, 48, 50, 58, 82, 84, 86, 88	55-9173	76
51-2033	28	55-7339	8, 12, 70, 74, 78, 82, 84	55-9208	94
51-270	12, 36	55-7340	50, 58	55-9211	64
51-273	18	55-7341	48, 50, 58, 70, 74, 78	55-9217	8, 12
51-336	34, 38, 92	55-7342	8, 12, 48, 86	55-9312	74
51-358	28	55-7344	48	55-9313	74
51-618	38	55-7347	18	55-9322	62, 64, 66, 68
51-619	40, 42, 70, 82, 88, 90	55-7349	86	55-9323	62, 68, 92
51-620	74	55-7354	50, 58, 70, 74	55-9338	88
51-621	92	55-7357	48	55-9346	38
51-801	70	55-7367	88	55-9380	74
55-1827	30	55-7370	42	55-9392	44
55-2001	48	55-7372	18, 20	55-9393	44
55-2074	38	55-7391	76	55-9395	44
55-2260	94	55-7404	50, 52, 58, 60, 88	55-9396	42
55-2262	92	55-7464	50	55-9402	66
55-2296	16, 22, 24	55-7713	92	55-9437	88
55-2324	12	55-7825	86	55-9442	84
55-2330	94, 96	55-7830	32	55-9444	38, 44, 50, 58, 92
55-2550	90	55-7862	88	55-9541	16, 72, 74, 76, 78, 82, 84
55-2636	48	55-7864	32	55-9759	20, 40
55-2686	94				
55-2864	74				

INDEX NUMERICAL BY PART NUMBER

55-9912	18	66-7183	16, 20, 28	91-8142	34
60-285	6, 14, 18, 24	66-7543	24, 30	91-8154	98
61-1305	24, 30	66-7812	14, 18, 28	91-8195	70, 74
61-154	32	66-8054	16, 20, 26, 28	91-8199	70, 74
61-175	14	66-874	16, 20	91-8217	54
61-1839	16	66-8811	14, 18, 30	91-8244	94
61-1840	16	66-9181	14	91-8252	82
61-1843	14	66-9194	32	91-8256	70, 74
61-1844	14	66-9447	24, 30	91-8466	8, 12
61-1845	14	66-9842	28	91-8467	34
61-1846	14	66-9906	14, 20, 24	91-8474	70, 74, 78
61-1847	14, 20, 24	67-1575	24, 30	91-8475	72, 78, 98
61-1848	14, 18	67-1889	14, 18, 24	91-8629	34
61-1849	14	67-1890	14	91-8634	34
61-1850	16	67-1921	16, 22, 26	91-8663	82, 84
61-1852	14	67-1922	12, 16, 22, 26	91-8694	98
61-1853	14	67-1923	16, 22, 24	91-8695	98
61-2048	16, 20, 24	67-1991	18	91-8696	98
61-2049	16, 22, 24	77-1401	6, 8, 12, 34	91-8697	98
61-2050	16, 20, 24	77-1498	6, 8, 12, 34	91-8705	50, 58
61-2051	16, 22, 24	77-2467	82	91-8707	50, 58
61-2052	16	77-2870	90	91-8708	50, 58
61-2053	16	78-1117	8	91-8709	50, 58
61-2054	16	78-1167	6	91-8725	50, 58
61-2057	16, 20, 26, 36	78-1196	12	91-8726	52, 58
61-2117	16	78-1349	8	91-8728	72, 76, 78
61-2118	28	78-1524	8	91-9021	28
61-2119	28	845-2009	44	91-9039	70, 76
61-2162	16, 18, 24	845-2010	38	91-9040	70, 74
61-2238	18	91-1779	16	91-9041	70, 74
61-2271	72, 80	91-1800	20	91-9048	82, 84
61-2464	20, 26	91-2205	54	91-9272	38
61-2465	20, 26	91-2209	54	91-9328	8, 12
61-2466	20, 26	91-3238	48	91-9330	92
61-2467	16, 18, 24	91-4218	50	91-9331	92
61-2468	20, 24	91-4219	50	91-9380	44
61-2469	20, 24	91-4220	52	91-9381	44
61-2470	20, 24	91-4380	56	91-9382	44, 98
61-2471	18, 24	91-4774	16	91-9508	48
61-2472	18, 24	91-5005	50, 58	91-9511	76
61-2473	18	91-5006	50, 58	91-9596	98
61-2474	20, 24	91-5007	50, 58	91-9754	72, 76, 80
61-2475	18	91-5635	98	91-9778	98
61-2476	20	91-6560	74	91-9831	98
61-2477	18, 24	91-6627	30	91-9833	38
61-2569	18	91-6628	30	91-9834	64, 66
61-3502	20, 26	91-6988	48	91-9914	42
61-3503	24	91-758	18	91-9915	42
61-3504	24, 30	91-759	16, 22, 30	91-9922	92
61-3508	26	91-8100	82, 84	91-9923	92
61-3525	24, 30	91-8102	82, 84	91-9924	92
61-3542	24, 30	91-8103	82, 84, 86	91-9949	72, 80
61-443	16, 20, 24	91-8104	82, 84	91-9950	72, 80
61-5619	72, 80	91-8105	82	91-9951	72, 80
61-786	14, 18, 24	91-8106	82, 84, 88, 90	92-1218	98
66-4788	30	91-8107	82	92-206	62, 64
66-6607	16, 20, 28	91-8108	70, 74, 78	92-219	32
66-6610	28, 30	91-8134	70, 74	92-2228	20, 24
66-7182	14, 18, 28, 30	91-8140	34	92-2229	18

INDEX NUMERICAL BY PART NUMBER

92-2332	8	92-5660	34
92-234	34	92-5685	90
92-235	34	92-5686	90
92-236	38	92-5687	90
92-237	38	92-722	92
92-238	38	92-860	38
92-239	38	92-891	72, 74, 78
92-240	86	98-5454	40
92-241	86	98-5532	50, 58
92-242	86	98-5772	92
92-243	66, 68, 98	98-5773	92
92-2585	98	98-5774	92
92-2586	98	98-5775	92
92-2587	10	98-5923	92
92-2588	14	98-5925	70, 74, 78, 96
92-2589	14	98-6236	70, 78
92-2773	92	98-6518	70
92-2774	92	98-6556	92
92-2775	8	98-6560	70, 78
92-2777	34	98-6562	8
92-2778	12	98-6563	76
92-2779	8	98-6564	12
92-2790	12	98-6565	92
92-2791	12	98-6566	8
92-2995	74	98-6771	72, 78
92-3391	20, 26	98-6784	44
92-3445	42	98-7410	72, 78
92-3446	44	98-7418	72, 78
92-3547	18	98-7424	72, 78
92-3548	20	98-7430	70
92-3549	20	98-7446	72, 78
92-3550	20	98-7691	78
92-3551	20	99-3281	94
92-3552	20	99-3685	38, 46, 66, 68
92-3553	20	99-4931	8
92-3554	44	99-7230	50, 58
92-411	82, 84, 88	99-7849	58
92-412	88		
92-413	88		
92-414	88		
92-415	88, 90		
92-416	88, 90		
92-417	88		
92-418	88		
92-419	88		
92-420	88		
92-425	8		
92-427	92		
92-428	66, 68		
92-4305	98		
92-440	82, 84, 98		
92-456	8		
92-458	8		
92-4724	98		
92-5201	90		
92-5392	98		
92-5520	38		
92-5521	88		
92-5547	58		

INDEX ALPHABETICAL BY DESCRIPTION

A

ACTUATOR **90**
 ADAPTER **16, 20, 26**
 ADAPTER - 9-pin D PC connector to USB **46**
 ADAPTER - 9-pin D PC to PC card **46**
 ADAPTER - compressor **16, 18, 24**
 ADAPTER - high side **28**
 ADAPTER - hose **82, 84**
 ADAPTER - push-on **44**
 ARM - pen lift **56**

B

BALL JOINT **88**
 BANDWRAP **94, 96**
 BARB - hose adapter **86**
 BATTERY **40**
 BATTERY - lithium **44**
 BEARING **90**
 BEARING - opposite end **6, 8, 12, 34**
 BEARING - shaft end **6, 8, 12, 34**
 BEARING - slide **82, 86**
 BLOCK - coil **8, 12**
 BLOCK - terminal **38, 40**
 BOARD - interface **88, 90**
 BOARD - relay **38**
 BOOT - switch **38**
 BOX - control **34, 40**
 BOX - recorder **50, 58**
 BRACKET **38**
 BRACKET - air vent **90**
 BRACKET - air vent handle **82, 84**
 BRACKET - battery **38**
 BRACKET - cable **48**
 BRACKET - cable restraint **48**
 BRACKET - diagram **38**
 BRACKET - exchanger **14**
 BRACKET - frame **70, 74, 78**
 BRACKET - grille **90**
 BRACKET - handle **82, 84**
 BRACKET - heat exchanger **20, 26**
 BRACKET - heater **34**
 BRACKET - hose **94**
 BRACKET - latch **50, 58**
 BRACKET - mechanical stop **88**
 BRACKET - motor **8, 12**
 BRACKET - motor box **88**
 BRACKET - motor mount **12**
 BRACKET - power cable **34**
 BRACKET - rear **90**
 BRACKET - receptacle **88**
 BRACKET - safety hook **72, 74, 78**
 BRACKET - sensor **8**
 BREAKER - circuit **42**
 BUSHING - plug **48**

C

CABLE - AFAM/AFAM+ **88, 90**
 CABLE - battery **40**

CABLE - compressor **34**
 CABLE - connecting **44**
 CABLE - data **46**
 CABLE - data download **46**
 CABLE - power **34, 48**
 CABLE - retriever plug **38**
 CABLE - Transfresh **92**
 CABLE & PLUG - retriever **64, 66, 68**
 CAP - charge port **16, 20**
 CAP - dust **46, 66, 68**
 CAP - dust cover **30**
 CAP - fitting **14, 18, 28, 30**
 CAP - plug **38, 62, 64**
 CAP - receptacle **64**
 CAP - screw **8, 12**
 CHAIN - cap **38, 46, 66, 68**
 CHANNEL - air **92**
 CHANNEL - fresh air **92**
 CHANNEL - Z **92**
 CHART **52, 54, 56**
 CHART - thermometer **60**
 CLAMP - dehydrator **18, 24**
 CLAMP - hook **76**
 CLAMP - hose **94**
 CLAMP - strap **16**
 CLAMP - suction tube **16**
 CLAMP - tube **16, 18, 20, 22, 30**
 CLAMP - valve **20, 24**
 CLIP - relay **38**
 COIL **16, 20, 26, 36**
 COIL - condenser **6, 14, 18, 24**
 COIL - evaporator **8, 12, 16, 22, 24, 26**
 COIL - valve **14, 20, 24, 34**
 COMPRESSOR - scroll **14, 18, 24, 28, 34**
 CONNECTOR **40, 44, 64**
 CONNECTOR - cross **40**
 CONNECTOR - grip **12, 48**
 CONNECTOR - harness **12**
 CONNECTOR - harness & sensor **8**
 CONNECTOR - liquid tite **36, 38**
 CONNECTOR - plug **38, 66, 68, 88**
 CONNECTOR - T **94**
 CONTACTOR **42**
 CONTACTOR - auxiliary **42, 62**
 CONTROLLER **44**
 COUPLING - outlet **30**
 COVER **72, 76, 78**
 COVER - exchanger **14**
 COVER - recorder **50, 58**
 COVER - terminal box **28**
 COVER - tube **8, 12**

D

DEHYDRATOR **14, 18, 24**
 DEVICE - door position sensor **84**
 DISK - air vent **82, 84, 86**
 DISPLAY - controller **44**
 DOOR - AFAM **90**

DOOR - control box **44**
 DOOR - controller **38**
 DOOR - evaporator **70, 74, 78**
 DRIVE - chart **54**

E

ELBOW - low side **28**
 ELEMENT **56**
 ELEMENT - thermo **54**

F

FAN - condenser **6**
 FAN - evaporator **8, 12**
 FILTER - gas sensor **8**
 FITTING - flare **16, 20**
 FITTING - harness **38**
 FITTING - high side **14, 30**
 FITTING - highside **28**
 FITTING - low side **16, 20, 28**
 FLATWASHER **6, 8, 12, 14, 16, 18, 20, 24, 26, 28, 30, 32, 34, 38, 40, 42, 48, 50, 52, 58, 70, 72, 74, 76, 78, 82, 84, 86, 88, 90, 96**
 FRAME - condenser **72, 76, 78**
 FUSE **38, 40, 44**

G

GASKET **6, 86, 90**
 GASKET - air vent **82, 84, 86, 88, 90**
 GASKET - controller **44**
 GASKET - cover **40, 50, 58**
 GASKET - door **80**
 GASKET - evaporator door **72, 76, 78**
 GASKET - flange **28**
 GASKET - gauge **32**
 GASKET - grille **96**
 GASKET - power connector **28**
 GASKET - receptacle **88**
 GASKET - round **32**
 GASKET - rubber extrusion **70, 78**
 GASKET - unit **72, 76, 78**
 GAUGE - suction pressure **32**
 GRILLE - condenser **70, 74, 78, 96**
 GRILLE - evaporator **92**
 GRILLE - fresh air **88, 90**
 GRIP - cable **6**
 GROMMET **6, 8, 10, 12, 40, 50, 58, 88**
 GUIDE - latch **50, 58**

H

HANDLE - air vent **82, 84**
 HANGER - dehydrator **14**
 HARNESS - condenser fan **6, 34**
 HARNESS - control box **34**
 HARNESS - evaporator **34**
 HARNESS - evaporator fan **8, 12**
 HARNESS - remote monitor **62**
 HARNESS - sensor **34**

INDEX ALPHABETICAL BY DESCRIPTION

HEAT EXCHANGER - economizer **14, 18, 24**

HEATER **34**

HINGE **74**

HINGE - air vent **82, 84**

HINGE - cover **38**

HINGE - door **44**

HINGE - evap door **74**

HINGE - frame **70**

HINGE - left **50, 52, 58**

HINGE - plate **88**

HINGE - right **50, 58**

HINGE SET - left **50**

HINGE SET - right **52**

HOLDER - fuse **38**

HOOK - strap **70, 76**

HOSE - drain **96**

HOSE - flex **94**

HOSE - sensor **10**

HOUSING - evaporator **8**

HOUSING - motor **88**

HOUSING - relief valve **72, 80**

I

INDICATOR **30**

INDICATOR - liquid **14, 18**

INDICATOR - volt **56**

INLET - fresh air **92**

INSERT - threaded **12**

INSULATION - heat exchanger **18**

INSULATION - mylar **20**

INSULATION - tube **20**

INSULATOR **38, 48**

INSULATOR - hinge **44**

INSULATOR - latch **70, 74**

INTERLOCK **42**

K

KEEPER - door latch **70, 74**

KEY - fan **12**

KEY - winding **54**

KEYPAD **44**

KIT - gasket & grease **28**

KIT - power cord **28**

KIT - sensor **34**

KIT - stylus **54**

KIT - thermistor **28, 36**

KNOB **70, 74**

L

LABEL - AFAM door position **90**

LABEL - air ventilation **86**

LATCH - cover **50, 58**

LATCH - door **70, 74**

LINKAGE **88**

LOCKWASHER **6, 8, 12, 18, 28, 30, 34, 38, 42, 44, 48, 50, 52, 58, 60, 82, 84, 86, 88**

M

MASTIC - heat transfer **18**

MECHANISM **54**

MODEM **44**

MOTOR - condenser fan **6, 34**

MOTOR - damper **88**

MOTOR - evaporator fan **34**

MOTOR - fan **8, 12**

MOUNT - cable tie **94**

N

NAMEPLATE - AFAM Door Position **98**

NAMEPLATE - Air Vent Door **98**

NAMEPLATE - Air Vent Handle **98**

NAMEPLATE - Arrow **8**

NAMEPLATE - Caution **38**

NAMEPLATE - Data A3 **98**

NAMEPLATE - data download **68**

NAMEPLATE - data download USDA **66**

NAMEPLATE - Do Not Open Below 0 C **82, 84**

NAMEPLATE - IR logo **98**

NAMEPLATE - On/Off **38**

NAMEPLATE - Phase Select **44**

NAMEPLATE - R404A **98**

NAMEPLATE - Scrubber A5 **98**

NAMEPLATE - Temperature

Conversion **98**

NAMEPLATE - Thermo King **98**

NAMEPLATE - TK **72, 76, 78, 98**

NAMEPLATE - USDA Connections **98**

NAMEPLATE - Warning **98**

NAMEPLATE - Warning English **98**

NAMEPLATE - Warning, Fan Start **98**

NAMEPLATE - Warning, Hot Components **98**

NAMEPLATE - Warning, Low Oxygen **98**

NAMEPLATE - Warning, Power Off **44**

NAMEPLATE - Warning, Scroll

Compressor **98**

NAMEPLATE - Weld **98**

NUT **6, 8, 12, 14, 18, 20, 24, 28, 32, 38, 40, 42, 44, 48, 50, 58, 70, 74, 78, 82, 84, 86, 88**

NUT - chart **56**

NUT - connector **48**

NUT - controller **44**

NUT - filter **14**

NUT - o-ring seal **14, 20, 24**

NUT - receiver tank **18**

NUT - speed **38**

NUT - wing **82, 84, 86**

NUTSTRIP **8**

NUTSTRIP - bracket **10**

NUT, CLIP & CORD **54**

O

OIL - compressor **28**

O-RING **14, 16, 18, 20, 26, 30, 54**

O-RING - suction **28**

P

PANEL - USDA receptacle **36, 64, 66, 68, 92**

PANEL - USDA, assembly **64**

PIN - clevis **90**

PIN - cotter **88, 90**

PIN - hinge **70, 74, 82, 84, 88, 90**

PLATE - air vent **82, 84, 86**

PLATE - bottom **42**

PLATE - box **50, 58**

PLATE - cable storage **70, 74, 78**

PLATE - cover **92**

PLATE - end terminal **40**

PLATE - guard **32, 70, 74, 78**

PLATE - keeper **50, 58**

PLATE - rear **92**

PLATE - recorder **56**

PLATEN **54**

PLUG **28**

PLUG - fusible **14, 18, 30**

PLUG - outlet **30**

PLUG - power **34, 48**

PLUG - seal **38**

PLUG - spare hole **66**

POCKET - sensor **72, 76, 80**

PORT - injection **72, 80**

PROTECTOR - edge **82, 84**

R

RAIL - din **42**

RAIL - terminal block **40**

RECEPTACLE **62, 64, 66, 68**

RECEPTACLE - power **48**

RELAY - power **38**

RETAINER - pin **88**

RETAINER - screw **44**

RIVET - bracket **38**

RIVET - cap **62, 64, 66, 68**

RIVET - channel **92**

RIVET - connector **66, 68**

RIVET - grille **92**

RIVET - hinge **74**

RIVET - housing **8, 72, 80**

RIVET - inlet **92**

RIVET - latch **50, 58, 70, 74**

RIVET - mount **94**

RIVET - panel **64, 66, 68**

RIVET - plate **50, 58, 92**

RIVET - plug **38**

RIVET - port **72, 80**

RIVET - receptacle **62, 64**

ROD - linkage **88**

ROD - push **54**

INDEX ALPHABETICAL BY DESCRIPTION

S

SCREW **16, 42, 82, 86**
 SCREW - air vent **86**
 SCREW - battery **40**
 SCREW - box **50, 58**
 SCREW - bracket **8, 12, 26, 34, 38, 48, 50, 70, 72, 74, 76, 78, 88, 90, 94**
 SCREW - cable **48**
 SCREW - channel **92**
 SCREW - clamp **16, 18, 20, 22, 24, 30, 76**
 SCREW - coil **6, 8, 12, 14**
 SCREW - compressor **28**
 SCREW - control box **40**
 SCREW - cover **8, 12, 14, 72, 76, 78**
 SCREW - dehydrator **18**
 SCREW - dehydrator clamp **20**
 SCREW - discharge valve **28**
 SCREW - disk **84**
 SCREW - door **44, 70, 74, 78**
 SCREW - flange **28**
 SCREW - gauge **32**
 SCREW - grille **70, 74, 78, 88, 90, 96**
 SCREW - ground **28**
 SCREW - guide **50, 58**
 SCREW - handle **82, 84**
 SCREW - hanger **14**
 SCREW - hinge **38, 44, 52, 58, 72, 74**
 SCREW - keeper **70, 74**
 SCREW - linkage **88**
 SCREW - motor **6, 8, 12**
 SCREW - plate **50, 58, 70, 74, 78, 82, 84, 92**
 SCREW - plate to box **42**
 SCREW - rail **40**
 SCREW - receptacle **48**
 SCREW - recorder **50, 58**
 SCREW - relay board **38**
 SCREW - sensor **8**
 SCREW - strap **70, 76**
 SCREW - tank **30**
 SCREW - thermostat **34**
 SCREW - transformer **42, 48**
 SCREW - vent **82**
 SCREW - vent hinge **84**
 SEAL - teflon fiber **18, 24**
 SEALER - locking **30**
 SEALER - polyurethane **92**
 SEALER - silicone grease pack **28**
 SEALER - thread **28, 30, 88**
 SENSOR **66, 68**
 SENSOR - gas **10**
 SENSOR - humidity **36**
 SENSOR - PT100 **64, 92**
 SHOULDER **14, 20, 24**
 SPACER **16, 20, 22, 28**
 SPACER - clamp **20, 24**
 SPACER - compressor **18**

SPRING **70, 74, 82, 84**

SPRING - heater **34**

STRAP - door **70, 76**

SWITCH - hpc0 **28, 34**

SWITCH - lpc0 **16, 20, 26, 34**

SWITCH - On/Off **38**

T

TANK - receiver **14, 18**

TANK - water cooled condenser **24, 30**

T-DRAIN **94**

TEE **14, 16, 18, 22, 24**

TEE - drain hose **96**

TERMINAL - pin **34**

TERMINAL - stop clip **40**

THERMOMETER **54**

THERMOMETER - recording **50, 56, 58**

THERMOMETER & BOX ASSEMBLY **58**

THERMOSTAT - defrost termination **34**

TIMER **56**

TRANSDUCER - discharge **22, 26, 36**

TRANSDUCER - suction **22, 26, 36**

TRANSFORMER **42, 48**

TRAY - high voltage **40**

TRIM - edge guard **8**

TUBE **24**

TUBE - coil to dehydrator **26**

TUBE - coil to flange **16**

TUBE - coil to receiver tank **14**

TUBE - coil to valve **16**

TUBE - condenser to condenser **24, 30**

TUBE - condenser to filter **30**

TUBE - condenser to tee **24**

TUBE - dehydrator to tee **14**

TUBE - equalizer **16, 20, 24**

TUBE - exchanger to coil **20, 24**

TUBE - expansion valve to exchanger **20, 24**

TUBE - expansion valve to inlet **16**

TUBE - expansion valve to tee **14, 16, 22, 24**

TUBE - filter **14, 18, 24**

TUBE - filter to tee **18**

TUBE - flange to coil **14**

TUBE - gauge **32**

TUBE - heat exchanger to evaporator **20, 24**

TUBE - liquid injection **14, 20, 24**

TUBE - receiver to condenser **18**

TUBE - receiver to dehydrator **18**

TUBE - stub **30**

TUBE - suction **20, 26**

TUBE - suction to ball valve **20, 26**

TUBE - suction to valve **16**

TUBE - tank to dehydrator **14**

TUBE - tee to distributor **16, 22, 24**

TUBE - tee to exchanger **14, 18, 24**

TUBE - tee to valve **14, 18, 24**

TUBE - tx bulb **20**

TUBE - valve to coil **14, 18, 24**

TUBE - valve to compressor **16, 24**

TUBE - valve to dehydrator **24, 30**

TUBE - valve to evaporator **16**

TUBE - valve to expansion **14, 20, 24**

V

VALVE **20, 26, 28**

VALVE - ball **20, 24, 26, 30**

VALVE - digital **16, 36**

VALVE - discharge **28**

VALVE - expansion **14, 16, 20, 24**

VALVE - pressure relief **72, 80**

VALVE - solenoid **14, 20, 24, 34**

VALVE - suction **28**

VALVE - vacuum **72, 80**

VENT - air **82, 88**

W

WASHER **6, 8, 12, 14, 16, 22, 44, 50, 70, 72, 74, 76, 78, 82, 84, 86, 88, 96**

WASHER - ground **28**

WASHER - insulating **8, 18, 26, 32, 38, 44, 50, 58, 84, 92**

WASHER - insulation **70, 74, 78, 84**

WASHER - insulator **34, 40, 42, 82, 84, 88, 90**

WASHER - sealing **28**

WASHER - shoulder **88**

WASHER - vibration damper **28**

WINDOW **50, 58**

INDEX ALPHABETICAL BY DESCRIPTION



Ingersoll Rand's Climate Solutions sector delivers energy-efficient HVACR solutions for customers globally. Its world class brands include Hussmann, a manufacturer of refrigeration and food merchandising solutions, Thermo King, the leader in transport temperature control and Trane, a provider of energy efficient heating, ventilating and air conditioning systems, building and contracting services, parts support and advanced controls for commercial buildings and homes.

Distributed by:

Thermo King Corporate

314 West 90th Street
Minneapolis, MN 55420
Direct (952) 887-2200